

Quick Guide for Ericsson W25

This is a basic quick guide to help with the initial installation of the W25 for internet access. We recommend customers also read the supplied manual before installing the W25.

Initial Setup:

Insert sim card: remove top lid on the W25 and insert sim above yellow sticker as shown

Antenna – Connect the supplied antenna

Power – connect power to the W25

Cable – connect the network cable to the LAN 1 port on the W25 and to your PC

Step 1)

Open a web browser such as Internet Explorer, enter <http://192.168.1.1> in the address bar and press enter.

This will open up the Ericsson web interface.

Login: user

Password: user (To change this password see the of the user manual)

Step 2)

The next step is to configure the W25 using the setup wizard.

To enter the wizard, click the [Configuration Wizard] button on the opening page.

Step 3)

Once you have opened the configuration wizard the first screen will ask for a sim password (Some sim cards will come from your service provider with a password others won't) once you have entered your pin click the next button.

Step 4)

The wizard will ask for your APN. (Your APN is provided to you by your network operator) You cannot complete the wizard without an APN.

Eg. for Telstra Mobile Data the APN (3G): telstra.internet

APN (2G): telstra.internet

Step 5)

On the next page, if your service provider has given you PPP authentication details, they can be entered here. If they have not provided these to you then proceed to the next step. This is where you can also enter your username and password if you have a Bigpond account.

Step 6)

If you wish to connect your computer to the W25 using WiFi, then tick the check box. If you just desire to use the network cable this does not need to be ticked.

Step 7)

On the next screen, you will see all the settings you have entered. If you are happy with these click finish.

You now should be able to access the internet using the Ericsson W25

SOFTWARE UPGRADES

Can be done remotely by downloading the latest firmware from www.ericssonw25.com and updating the unit via the Ericsson web interface.

If you purchased the W25 after the 09/05/08 your current firmware should be R10C

TROUBLESHOOTING

'Internet' LED Not Appearing

- Make sure you have entered the correct APNs in the web interface.
- Reboot the unit

Dial tone is not heard on a cordless phone

- The W25 can be sensitive to certain brands of cordless phones. We recommend the Uniden range for compatibility.
- If available power the W25 from a 240v power source, instead of using 12/24v. This may aid in getting the W25 to work with your cordless phone.
- Test the W25 using a corded phone to see if dial tone is present.

'Alarm' LED is on

- SIM card is not inserted correctly
- A PIN code is on the SIM card. You can enter the PIN code in the web interface or put the SIM card in a mobile phone and disable PIN code request.
- Telstra sim cards with a serial on the back of '1204' have issues with the W25 and will cause the unit not to recognise a sim card is present.

Unit does not connect to network and 'mobile network' LED continues to flash.

- Ensure the W25 is in a good signal area
- Under the 'Internet' tab in the web interface you will find the 'Cellular Band Selection' area, select from the drop down box your region or turn off the frequencies not required.
- If you have connections issues on Telstra's Next G network disable all frequencies except for 3G 850MHz

INFORMATION ON APNS

TELSTRA

telstra.internet – used for a pay as you go plan

telstra.datapack – used to access the data plans (idle time out is 2 hours)

telstra.corp – used to access Telstra IP WAN \ IP Wireless shared access

telstra.bigpond – used to access Bigpond accounts (will need to enter username and password)

telstra.wll – used specifically for customers using Telstra's Wireless Local Loop service

THREE

3netaccess – used for internet access

3services – used for Planet 3 + internet access

OPTUS

internet

VODAFONE

vfinternet.au